

miroMEDIA Online PnP

USER'S GUIDE



miroMEDIA Online PnP

User's Guide

Version 1.0/GB August 1996

700494

© miro Computer Products AG 1996

All rights reserved.

No part of this manual may be reproduced or transferred to other media without explicit written permission from miro Computer Products AG, Braunschweig, Germany.

Adobe™ and Acrobat™ are trademarks of Adobe Systems Inc.

IBM AT® is a registered trademark of International Business Machines Corp., Mwave™ and DynaSeg™ are trademarks of International Business Machines Corp.

MNP® is a registered trademark of Microcom, Inc.

Sound Blaster® and Sound Blaster Pro are registered trademarks of Creative Labs Technology, Ltd.

Windows™, Microsoft® and MS DOS® are registered trademarks of Microsoft Corp.


miro manuals are printed on chlorine-free paper using environmentally safe ink.

miro Computer Products AG has written this manual to the best of its knowledge, but does not guarantee that the programs/systems will fulfill the desires of the user.

No warranty is made as to the specifications of features.

miro retains the right to make alterations to the content of the manual without the obligation to inform third parties.


All tenders, sales, supply and manufacturing contracts from miro, including consultancy, installation and other contractual performance are subject exclusively to the General Sales and Delivery Terms of miro.



Contents

OVERVIEW	1
PRODUCT OVERVIEW	1
FEATURES	2
WHAT IS PLUG & PLAY?	2
SYSTEM REQUIREMENTS	3
PACKAGE CONTENTS	3
miroMEDIA ONLINE PnP BOARD DIAGRAM	4
INSTALLATION	5
INSTALLING THE miroMEDIA ONLINE PnP BOARD	5
CONNECTING EXTERNAL DEVICES	6
INSTALLING YOUR miroMEDIA ONLINE PnP SOFTWARE	7
TESTING THE HARDWARE	11
Mwave Quick Test	11
Modem test	11
Sound test	13
UNINSTALLING THE miroMEDIA ONLINE PnP SOFTWARE	13
TROUBLESHOOTING	15
INSTALLATION PROBLEMS	15
GENERAL PROBLEMS	16
CHANGING SETTINGS USING THE DEVICE MANAGER	16
How to use the Device Manager	17
MODEM PROBLEMS	19
SOUND PROBLEMS	20

TECHNICAL DATA	22
TELEPHONE SUBSYSTEM	22
AUDIO SUBSYSTEM	22
MICROPHONE INPUT	22
AUDIO INPUT	23
AUDIO OUTPUT	23
CURRENT CONSUMPTION	24
MODEM DATA	24
FAX DATA	24
VOICE DATA	25
APPENDIX	I
PIN ASSIGNMENTS	I
Telephone connection	I
Internal connector	I
Microphone input	II
Audio input/output	II
MIDI/joystick connector	II
DMAS, IRQS, AND ADDRESSES	III
DMA channel	III
Interrupts (IRQs)	IV
I/O addresses	V
miroMEDIA Online PnP Ressources	V
Chart your system settings	VI
AT COMMANDS	VII
Command mode vs. on-line state	VII
Syntax of AT commands	VII
Conventions of the AT command overview	VII
The AT Commands	VIII
S REGISTERS	XV
MODEM MESSAGES	XVII
ERROR MESSAGES	XVIII
GLOSSARY	XIX
INDEX	



For your own safety

In the interest of your own safety and the flawless functioning of your new product and computer system please note the following:

Before opening the computer make sure that the power plug is disconnected from the main socket.


Computer components are sensitive to static charge. Divert any electrostatic charge from your person before touching the components with your hands or any tools.

Make sure that the components you want to add to the computer are in compliance with the computer's characteristics.

Avoid address conflicts!



For changes that have occurred after the manual has been printed, refer to the README file/s on the CD supplied with your system! In the Windows File Manager double-click the README file to get the latest information.



About the manual

This manual explains how to install and use the miroMEDIA Online PnP hardware and software.

Subheadings

In the margins are subheadings to help you quickly find your way through this manual.



Important text passages are marked with the “notepad” and this format.

Numbers mark step by step instructions:

1. Start Windows.

Bullets mark instructions for optional steps the order of which is not important:

- Connect the board to the microphone.

All keyboard commands appear in this font:

install <↵>

represents the enter key.

Menus, commands, options or buttons which the user can select are written in *italics*.



Overview

Thank you for purchasing the miroMEDIA Online PnP board.

Your miroMEDIA Online PnP board is an all-in-one communication and sound system—it provides:

- ♦ Complete telephony functionality
- ♦ Extensive fax/modem features
- ♦ Access to on-line services and Internet
- ♦ High-quality wave sound play back
- ♦ High performance sound board
- ♦ ... and more.

This manual contains several terms from the field of telecommunication or multimedia you might not be familiar with. Refer to the glossary contained in the documentation which is located on the CD-ROM.

PRODUCT OVERVIEW

miroMEDIA Online PnP provides numerous functions that would otherwise be available only by purchasing several different circuit boards. On a single board, a fax machine, modem, telephone, telephone answering device, and 16-bit wave table sound board was incorporated. You can use your MiroMEDIA Online PnP board to record and play back sounds and music, thereby enhancing the realism of game software.

miroMEDIA Online PnP is compatible with the Telephone Application Interface (TAPI).

Your MiroMEDIA Online PnP board utilizes the Mwave technology developed by IBM. The board contains the MWAVE MDSP-2780 (DSP is an abbreviation for Digital Signal Processor).

The Mwave V.34 modem runs as realtime task on the Mwave DSP and works together with the modem device driver on the x86 host. The Mwave Manager allows the modem device driver to load the required modules/segments in real-time and to remove segments which are no longer in use. This means that the DSP resources are automatically and dynamically managed. This feature, called DynaSeg™, provides an enormous flexibility and makes for example simultaneous data/voice transmission possible with a V.34 modem.

FEATURES

- | | |
|------------------------|--|
| Modem/Fax | <ul style="list-style-type: none">♦ Modem support with a data transfer rate up to 33,600 bps♦ Fax support with a data transfer rate up to 14,400 bps, V.17♦ Connection to existing telephone lines♦ Parallel operation with your existing telephone♦ Telephone and data transmission over one telephone line (Mwave DSVD = Voice over data function)♦ Call answering functions♦ Full duplex speaker phone for hands-free operation♦ Automatic discrimination between modem, fax, and voice data |
| Sound and Games | <ul style="list-style-type: none">♦ Soundblaster Pro compatibility♦ Stereo Line-In input with CD recording quality♦ Stereo Line-Out output with CD playback quality♦ Microphone input with gain control for dynamic and electret microphones♦ Data and audio possibilities of switching over and mixing the audio inputs and outputs♦ Connector for two joysticks♦ Qsound for 3D sound effects♦ MIDI-MPU-401 (under DOS and Windows)♦ MPC3-compatible |

WHAT IS PLUG & PLAY?

Your miroMEDIA Online board is Plug & Play-compatible. Before Windows 95 has been introduced, the user always had to take some hurdles when installing a new hardware component. Often the user had to set some jumpers on the board before the hardware installation. After having inserted the board into the computer he had to install the driver software and to select interrupts, DMA channels and/or IRQs using a configuration tool. The Windows 95 Plug & Play technology puts an end to this. Whether the computer system includes Plug & Play-compliant or legacy (non Plug & Play-compliant) components, Windows 95 can automatically detect and configure them. After having installed a new hardware component, Windows 95 detects that a new hardware component has been found, identifies the resources (IRQs, addresses, and DMAs) that are available, the resources that are used by other hardware components and adds the configuration information for the Plug & Play device to the Registry. Then, the device drivers are installed based on the Registry settings.

Your MiroMEDIA Online PnP board is fully compliant with the Intel ISA Plug & Play Specification 1.0a.

SYSTEM REQUIREMENTS

The following table shows the minimum hardware and software requirements for using your miroMEDIA Online PnP hardware and software. If your systems does not meet the minimum requirements, contact your reseller for upgrade information.

Component	Minimum Requirement	Note
Computer System	486 processor operating at 66 MHz	
RAM	8 MB	16 MB recommended
Expansion Slot	One free 16-bit ISA or EISA slot	
Operation systems	Windows 95	
Hard Disk Space	40 MB	
	CD-ROM Drive	Required for software installation

PACKAGE CONTENTS

Before you start the installation, make sure that your system is complete^{*}:

- ♦ miroMEDIA Online PnP board^{**},
- ♦ microphone,
- ♦ CD-ROM with system software and manual files,
- ♦ telephone cable,
- ♦ telephone adapter cable[†],
- ♦ Quick Installation Guide,
- ♦ *optional*:
miroMEDIA Radio upgrade: stereo tuner with RDS function.

If any parts are missing, please contact your reseller.


^{*} Depending on the delivery scope, the actual package contents may be different from the package contents listed in the manual.

^{**} For model and serial number of your miro board refer to the label on the board.

[†] Only for some countries.

miroMEDIA ONLINE PNP BOARD DIAGRAM

The following diagram identifies the important components on your miroMEDIA Online board. Take a few moments to study the diagram and familiarize yourself with the components and their respective names.





Installation

This chapter contains step-by-step instructions for installing your miroMEDIA Online PnP hardware and system software.

To install the miroMEDIA Online PnP board, you need a screwdriver for removing and re-installing your computer's cover and expansion slot screws.

If you already have a fax or modem card installed, we recommend you to remove it. Although you can use two fax/modems if you have a free COM port, you might experience problems in Windows or other applications.

INSTALLING THE miroMEDIA ONLINE PNP BOARD

It is extremely important that you always discharge any static electricity from your body before handling any of your computer components, including your miroMEDIA Online PnP board. To do so, touch any bare metal surface, such as the power supply unit inside your computer after removing its case. Failure to discharge static electricity can damage your computer system components.

Please read all steps in this section before you begin installing your miroMEDIA Online PnP board/circuit board.

To install your miroMEDIA Online PnP board, proceed as follows:

1. If your computer system is turned on, shut it down completely, and turn off all peripheral devices.
2. Disconnect the power cord and any cables connected to the back of your computer.



If you have several cables connected to your computer, you might find it helpful to identify them prior to disconnecting. Use colored pens, masking tape, or whatever method will help you reconnect each cable to its correct location.

3. Remove the cover from your computer system.
Refer to your computer system manuals if you need help with this step.
4. Carefully touch the computer's power supply unit, or any bare metal surface, to discharge all electrostatic energy stored in your body.
5. Select an empty 16-bit ISA or EISA expansion slot to insert the miroMEDIA Online PnP board. If you don't have a slot available, remove one of your existing boards to make room.
6. Remove the expansion slot shield at the back of your computer.
7. Remove your miroMEDIA Online PnP board from its antistatic package.

8. Carefully insert the miroMEDIA Online PnP board into the expansion slot you've selected.
Do this step carefully. Hold the board with both hands at its top edge. Use a gentle, end-to-end rocking motion to work the board connectors into the expansion slot. When you think the board is firmly seated, check it one last time.




If you have trouble seating the board in the slot, don't force it. Instead, remove the board and check it visually for bent or broken connectors. Then, reinstall the board slowly and carefully.

9. Fasten the miroMEDIA Online PnP board's bracket to the expansion slot opening at the back of your computer. Use the screw that held the expansion slot shield or the board you removed from the slot.
10. Replace the cover on your computer and reconnect all cables you disconnected earlier.

CONNECTING EXTERNAL DEVICES

Once you successfully install your miroMEDIA Online PnP board, you can connect a wide variety of devices to it, depending upon your needs. The diagram below shows some of the possibilities.

- To use the telephone, fax, and/or modem functions available on your miroMEDIA Online PnP board, use a telephone cable.
- To use a microphone, connect the device to the microphone input connector on your miroMEDIA Online PnP board.
- To use a CD player, tape deck, or radio with your miroMEDIA Online PnP board, attach the device to the Audio Input connector on your miroMEDIA Online PnP board.



- To direct audio output to active (self-powered) speakers, attach the device to the Audio Output connector on your miroMEDIA Online PnP board.
- To use a MIDI device or joystick with your miroMEDIA Online PnP board, attach the device to the MIDI/Joystick connector on your miroMEDIA Online PnP board. This connection requires a suitable cable with a 15-pin, D-type connector.
To use two joysticks, use a joystick Y-adapter cable in conjunction with a suitable cable with a 15-pin, D-type connector.

INSTALLING YOUR miroMEDIA ONLINE PNP SOFTWARE

After having installed a new hardware component, Windows 95 automatically detects that a new hardware component has been found, identifies the resources (IRQs, addresses, and DMAs) that are available, the resources that are used by other hardware components and adds the configuration information for the Plug & Play device to the Registry. Then, the device drivers are installed based on the Registry settings.

During installation, you have the opportunity to specify the disk and directory where you want to install various components. We recommend you take a few moments to plan which disk and directory you intend to use. It's best to do your planning ahead of time because once installation begins, you won't be able to explore your disks.




For maximum efficiency, you might want to defragment the drive you're going to use before installing your miroMEDIA Online PnP software. If the drive is highly fragmented, your software cannot run at optimum speed. Several utility programs are available for defragmenting disks.

Your miroMEDIA Online PnP package contains one system software CD-ROM (Compact Disc).


After you installed the miroMEDIA Online PnP board in your computer, Windows 95 detects the board automatically.

After the Windows 95 startup the *New Hardware Found* dialog box appears.


1. In this dialog box, click *the Driver from disk provided by hardware manufacturer* option. Click *OK*.




2. Insert the CD-ROM from the miroMEDIA Online PnP package contents.
3. In the *Install from disk dialog box* click *Browse*.




4. Go to your CD-ROM drive and select the MWDSPA03.INF file. Click *OK*.



5. In the *Install from disk* dialog box click *OK*.



6. In the next dialog box, enter the desired location for your Mwave software. Click *OK*.




The software for your miroMEDIA Online PnP board is now copied to your hard disk.

7. In the *System Settings Change* dialog box, click *Yes* to restart the computer.



Windows 95 will find the miroMEDIA Online PnP devices and all windows are created.




Now the miroMEDIA Online PnP software installation is complete. The miroMEDIA Online PnP program group has been created.

TESTING THE HARDWARE

Mwave Quick Test

After you completed the software installation, you can test your hardware with the Mwave Quick Test utility contained in the *Mwave Release x.xx* group.



The Mwave Quick Test Utility allows you to test the individual functions of the board (*Audio, Modem, Microphone, Handset*).


In case of problems, refer to the Troubleshooting section.

Modem test

Windows 95 is able to identify and to test a modem.


To check if Windows 95 is able to identify the modem, do the following:

1. In the *Start* menu select *Settings*.
2. Select the *Control Panel*.
3. Select *Modems*.




4. Select the *Diagnostics* tab.

The tab shows you to which port the modem uses.



5. Click on *More Info*.

This dialog box shows you additional information concerning your miroMEDIA Online PnP.



In case of problems, refer to the Troubleshooting section.

Sound test

To test the sound functions of the miroMEDIA Online PnP, do the following:

1. In the *Start* menu select *Programs*.
2. Select *Accessoires*.
3. Select *Multimedia* and *Media Player*.

Now you can play back a MIDI or a Wave file to test the sound functions of your miroMEDIA Online PnP.

In case of problems, refer to the Troubleshooting section.

UNINSTALLING THE miroMEDIA ONLINE PNP SOFTWARE


Before you uninstall the Mwave software be aware that all other files in the Mwave directory are also deleted by the Windows 95 Uninstall program. Remove the files you want to keep from the Mwave directory. To uninstall the Mwave software, proceed as follows:

1. From the *Start* menu select *Settings*.
2. Select *Control Panel*.
3. Select *Software*.
4. Select the *Install/Uninstall* tab.



5. Select the items you want to uninstall and click *Add/Remove*.

A warning message appears notifying you that all files in the Mwave directory will be deleted.



6. To remove the Mwave software, confirm the message.

7. After you deinstalled the software, restart the computer.



Troubleshooting

This section describes problems you might encounter when using your miroMEDIA Online PnP. The probable cause and possible solutions for each problem are provided.

INSTALLATION PROBLEMS

- Mwave Adapter not detected** Normally indicates that your miroMEDIA Online PnP board is not properly seated in its expansion slot.
Shut your computer system down and check the installation of your miroMEDIA Online PnP board. Refer to “Installing miroMEDIA Online PnP” for instructions on installing your board.
- AUTOEXEC.BAT** Because the installation software enters some SET commands in the AUTOEXEC.BAT, make sure these are set and that enough free memory is available. You can check this by entering the **set** command in the DOS prompt. The following variables should be shown:
- ```
SET MWPATH=C:\MWW\DLL;C:\MWW\MWGAMES;C:\MWW\DSP
SET BLASTER=A220 I5 D1
SET LIBPATH=C:\MWW\DLL
SET MWROOT=C:\MWW
SET PATH=XXX; C:\MWW\DLL;
```
- XXX stands for the rest of the path. The **SET BLASTER** variable has to be correct especially for DOS games.
- EMM386** Under Windows 95 you should never use EMM386!
- Motherboard** On some mother boards there may be problems due to memory optimization.
- BIOS** Please make sure that the required IRQs (especially the DSP IRQ of the miroMEDIA Online PnP) will not be used for the automatical management of the PCI slots—if present—. If necessary, disable the automatical allocation of the IRQs. This is absolutely necessary for Windows 3.1x and DOS.
- ISA slot** Please make sure that the miroMEDIA Online PnP is seated firmly in the ISA slot on your mainboard.

**Bus clock** Please check, if the ISA bus clock of your computer is 8.33 MHz at the most. If the ISA bus clock is higher the miroMEDIA Online PnP may not function properly. On older mainboards you can change the ISA bus clock using the jumper on your mainboard, for new mainboards only the BIOS has to be changed. For more information, refer to the manual of your mainboard.

## GENERAL PROBLEMS

### **Your systems reports address conflicts.**

When Windows 95 detects that two PCI devices want to use the same resources, it can solve the problem by allocating new resources. It will do the same when an ISA Plug & Play board and a PCI board have a conflict. If Windows 95 does not find a suitable substitute for addresses which are used by two devices, it disables the PCI device and shows this in the Device Manager. Then, the user has to search for free resources himself.

On many new PCI boards a conflict often occurs with the integrated parallel interface. Windows 95 expects that IRQ 5 (LPT2) or IRQ 7 (LPT1) is allocated to this interface because otherwise it cannot use the printer port. Many PCs, however, use these interrupts for sound or network boards. Under DOS this is no problem. Under Windows 95, which uses this IRQ to print in the background, this is not possible. The sound or network board has therefore to receive another IRQ.

Also with some motherboards which have a PS/2 mouse port conflicts may occur. Even if the mouse port is not connected, some boards lead the IRQ 12 to the controller component. If this interrupt is not registered as used in the Plug & Play BIOS, it may happen that the BIOS uses it for a PCI device. To avoid this, disable the IRQ manually via the Plug & Play part of the BIOS (usually assigning “used from ISA” to IRQ 12 suffices).

It is also possible that Windows 95 lets itself deceive by “phantom devices” e.g. PCI IDE adapters. To avoid this, start your computer in the secure mode. Open the *Device Manager* (*Start, Settings, Control Panel, System*) and remove the device via *Properties* and *General* from the current configuration. Deleting the device which is not used does not help because Windows 95 will find it next time the system is started and will try again to integrate it. If it is only removed from the current configuration as described it will still be there but it is, however, disabled. In the Device Manager it is marked with a red cross.

## CHANGING SETTINGS USING THE DEVICE MANAGER

After Plug & Play-compliant devices have been installed, Windows 95 identifies these devices and looks for free resources. If the devices which just have been installed do not want to use the resources which are occupied by the devices already installed, the settings should not change. If the devices request resources which are already used, the settings might change.

Therefore it is not recommended to change resource settings for a Plug & Play-compliant device because this would make it impossible for Windows 95 to allocate resources freely.

In some cases, for example if a conflict occurs, it may be necessary that a user has to change the resource setting after they have been configured. Then, a message should appear telling the user what he has to do. If you have to change the configuration manually, select *System* in the *Control Panel* and click *Device Manager*.

You can do either of the following:


- ♦ Look for a free resource, and allocate that resource to a device.
- ♦ Disable a conflicting Plug & Play-compliant device.
- ♦ Disable a legacy device by removing it and not loading the drivers.
- ♦ Reallocate the resources.



Changing the resource settings using the Device Manager can cause conflicts! Only experienced users should use the *Device Manager*.


## How to use the Device Manager

You find the Device Manager under *Start, Settings, Control Panel, System*. Here you can view the configuration of the devices you installed in your computer.




Yellow circles with black exclamation marks tell you that a conflict occurs with this device. A red cross means that this device has been recognized by Windows95 but that the user switched it off manually. It does not use any resources.


To switch a device off, disable the check box in the dialog box you see below.



Here you can view the resources that are used and change the configuration.



To do so, switch off the automatical settings and select the highest basic configuration possible. Then you can change the resources in the admissible range. Conflicts that may occur are shown in the window below.



## MODEM PROBLEMS

### **The modem does not work.**

If the modem does not work, first check to make sure that

- ♦ the telephone cable is connected correctly,
- ♦ no conflicts occur in the Device Manager,
- ♦ your country has been selected in the Country Selection program,
- ♦ in case you work on a PBX, make sure you disabled the option for waiting for the dial tone (*Start/Settings/Control Panel/Modem*).

### **Your modem is not functioning—it starts, but the communication program does not run.**

Normally due to a conflict between assignments for the COM interface or interrupts. Check if the COM interface and interrupt assignments of the modem and of the application program correspond. If a conflict exists, make the necessary re-assignments.

### **Your system reports a COM interface conflict, but the COM interface is not in use.**

Your computer is using a COM interface assignment of its own with the same number as the COM interface used by your miroMEDIA Online PnP. You need to deactivate the COM interface that is being used by your computer. You can normally accomplish this by running the BIOS Setup program when starting your computer. See your computer documentation for complete instructions.

Under Windows 95, you can also disable the COM interface using the Device Manager.

### **Modem does not answer/is not accessed by the application**

Please check, if the COM port specified during the configuration is free and has not been used yet. In general, you should use COM port 4 and assign COM1 to the mouse. (Note: This could lead to problems with older graphics boards containing the S3 chip set because those use the I/O port 02E8h, this however, is already used by COM4).

You can also assign COM3 to miroMEDIA Online PnP, then you have to assign the mouse to COM 2. COM1 and COM2 are mostly occupied so that they cannot be selected. In general, the mouse IRQ should not be the same as the modem IRQ.

Note: Windows 95 manages the IRQs and address ranges of the COM interfaces dynamically as far as the PC BIOS admits this. This avoids conflicts. It may happen that the COM interface of miroMEDIA Online PnP receives, e.g. the interrupt **IRQ 9**.

Please check to make sure if your communications or fax program permits this setting. With some old programs this is not possible. In this case, use the Windows 95 Device Manager to allocate the IRQ differently.



### **Dialling not possible with modem or FAX**

If you operate the miroMEDIA Online PnP together with a PBX, it is required to add "X3" to the initialisation string. In this way, the miroMEDIA Online PnP dials the desired number although you hear the busy tone or the tone of the PBX. Please make sure that you also enter the PBX number.

### **Board does not recognize incoming calls**

If this is the case, you probably use the miroMEDIA Online PnP together with a PBX. Some PBXs send tones which are not standardized. These are not recognized by miroMEDIA Online PnP.

Please consult the person who is in charge of your PBX. He/she should adapt the tones for internal and external calls to the standard signal.

## **SOUND PROBLEMS**

### **Sound does not play.**

If sound does not play, first check that

- ♦ the audio cable is connected correctly,
- ♦ the sound is not muted in the Windows 95 mixer which is located in the task bar on the right-hand side,
- ♦ no conflicts occur in the Device Manager.

Some newer computers, such as Pentium models, offer limited sound functionality. These functions occupy a DMA Channel and an Interrupt.

You need to deactivate your computer's sound functions in its BIOS Setup / in the Device Manager of Windows 95. You can access the functions during systems startup. See your computer's documentation for details.

**The microphone does not work.**

If the microphone does not work, make sure that

- ♦ the microphone cable is connected,
- ♦ no conflicts occur in the Device Manager,
- ♦ the microphone sound is not muted in the Windows 95 mixer which is located in the task bar on the right-hand side; to check this go to the *Options* menu in the mixer application, to *Properties*, select *Adjust volume for ... Other, Audio-Input Mixer*, enable *MIC Source*, then disable the *Mute* option in the mixer for the microphone controls. The controls for the microphone should be set to low.

**Your speakers emit a ‘whistling’ sound.**

Normally occurs when there is feedback between your speakers and your microphone.

Relocate your microphone so that it does not point directly at your speakers or change the microphone sensitivity in your application.



## Technical data

---

|                   |                         |
|-------------------|-------------------------|
| <b>Bus System</b> | 16-bit ISA or EISA Slot |
| <b>Processor</b>  | Mwave MDSP-2780         |

### TELEPHONE SUBSYSTEM

|                                   |                |
|-----------------------------------|----------------|
| <b>Connector</b>                  | RJ-11 Socket   |
| <b>Sampling Rate</b>              | 9.6 kHz        |
| <b>Resolution</b>                 | 13 bits linear |
| <b>Transmit/<br/>Receive Rate</b> | Max. 33.6 kbps |

### AUDIO SUBSYSTEM

|                      |                       |
|----------------------|-----------------------|
| <b>Sampling Rate</b> | 44.1 kHz/Channel      |
| <b>Resolution</b>    | 16-bit linear/Channel |

### MICROPHONE INPUT

|                                              |                                                                                                                                  |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Connector</b>                             | Mono 3.5 mm jack socket                                                                                                          |
| <b>Microphone<br/>Types</b>                  | Mono Dynamic, Electret Battery-Operated                                                                                          |
| <b>Input<br/>Impedance</b>                   | 2 k $\Omega$                                                                                                                     |
| <b>Electret mic<br/>bias voltage</b>         | 3.3 V with 3.3 k $\Omega$ impedance                                                                                              |
| <b>Maximum mic<br/>input voltage</b>         | -26 db                                                                                                                           |
| <b>Minimum mic<br/>input voltage</b>         | -70 db                                                                                                                           |
| <b>Microphone<br/>input gain</b>             | +26 db or +46 db                                                                                                                 |
| <b>Microphone<br/>frequency<br/>response</b> | 20 Hz - 20 kHz +/- 3 db with +26 db gain<br>20 Hz - 13 kHz +/- 3 db with +46 db gain<br>20 Hz - 13 kHz +/- 3 db with +70 db gain |

|                |                                          |
|----------------|------------------------------------------|
| <b>S/(N+D)</b> | 77 db with +26 db gain at 20 Hz - 20 kHz |
|                | 68 db with +46 db gain at 20 Hz - 20 kHz |
|                | 60 db with +70 db gain at 20 Hz - 20 kHz |

## AUDIO INPUT

|                                      |                                           |
|--------------------------------------|-------------------------------------------|
| <b>Connection</b>                    | Stereo 3.5 mm jack socket                 |
| <b>Maximum input voltage</b>         | 1 Vrms= + 6 db = 5.6 Vpp                  |
| <b>Input impedance</b>               | 20 k $\Omega$                             |
| <b>Signal/(Noise + Distribution)</b> | 82 db at 1 kHz<br>79 db at 20 Hz - 20 kHz |
| <b>Frequency Response</b>            | 20 Hz - 20 kHz (+1 db/-1 db)              |

## AUDIO OUTPUT

|                                    |                                              |
|------------------------------------|----------------------------------------------|
| <b>Connection</b>                  | Stereo 3.5 mm jack socket                    |
| <b>Maximum Input Voltage</b>       | 1 Vrms= +0 db = 2.8 Vpp at 1 k $\Omega$      |
| <b>Output impedance</b>            | 33 $\Omega$                                  |
| <b>Minimum headphone impedance</b> | >30 $\Omega$                                 |
| <b>S/(N+D)</b>                     | 80 db at 1 kHz at 10 k $\Omega$              |
| <b>Frequency Response</b>          | 20 Hz - 20 kHz + 1 db/-1 db at 10 k $\Omega$ |

## CURRENT CONSUMPTION

- +5V, app. 1.2 A
- +12V, app. 0.08 A
- 12V, app. 0.06 A

## MODEM DATA


- ♦ Asynchronous operation through the COM interface
- ♦ Modem standards:
  - ITU-T V.34 33.6 kbps
  - ITU-T V.32bis/14.4 kbps
  - ITU-T V.32/9600 bps
  - ITU-T V.23/1200 bps/75
  - ITU-T V.22bis/2400 bps
  - ITU-T V.22/1200 bps
- ♦ Protocol standards:
  - ITU-T V.42 LAPM error correction
  - ITU-T V.42bis data compression
- ♦ MNP Class 2-4 error correction
- ♦ MNP Class 5 data compression
- ♦ Dynamic Rate Renegotiation
- ♦ Automoding
- ♦ Hayes AT command repertoire-compatibility
- ♦ Call status display, Auto-dial
- ♦ DTMF and pulse dialling \*pulse dialling only for Germany

## FAX DATA

- ♦ Call status display
- ♦ Auto-dial
- ♦ Tone and pulse dialling (pulse dialling only for Germany)
- ♦ G3 transmission operation
- ♦ ITU-T V. 17 14400 bps
- ♦ ITU-T V29/9600 bps
- ♦ ITU-T V.27ter 4800 bps
- ♦ ITU-T.4
- ♦ ITU-T.30
- ♦ TR-29.2 Class 2, FaxClass 2 compatible
- ♦ TR-29.2 Class 1, FaxClass 1 compatible
- ♦ Manual sending/receiving

## VOICE DATA


- ♦ Windows UniModem-V support
- ♦ Windows 95 TAPI support
- ♦ Full-duplex speakerphone
- ♦ DTMF detection and passing



## PIN ASSIGNMENTS

This appendix defines the pin assignment for the various connectors in your miroMEDIA Online PnP board.

### Telephone connection



| Pin | Assignment   | Pin | Assignment   |
|-----|--------------|-----|--------------|
| 1   | line a       | 2   | line b       |
| 3   | telephone a2 | 4   | telephone b2 |
| 5   | not used     | 6   | not used     |

### Internal connector

|   |             |
|---|-------------|
| 8 | • MicIn     |
| 7 | • Gnd       |
| 6 | • nc        |
| 5 | • missing   |
| 4 | • Left out  |
| 3 | • Gnd       |
| 2 | • Gnd       |
| 1 | • Right out |

Pin 8 (MicIn):

Use an internal cable to connect the microphone for the voice-modem function.

Pins 7, 3, 2 (Gnd):

Ground for Mic (7), Left out (3) and Right out (2)

Pin 6 (n.c.):

Not connected.


Pin 4 (Left out):

Left channel of the received signal of the telephone line.

Pin1 (Right out)


Right channel of the received signal of the telephone line.

## Microphone input




*Stereo 3.5 mm Jack Plug*

## Audio input/output



*Stereo 3.5 mm Jack Plug*

## MIDI/joystick connector



*D-Sub 15 Socket*

| Pin | Assignment                 | Pin | Assignment                 |
|-----|----------------------------|-----|----------------------------|
| 1   | + 5 V                      | 2   | Joystick A:<br>button 1    |
| 3   | Joystick A: x<br>Direction | 4   | Earth                      |
| 5   | Earth                      | 6   | Joystick A: y<br>Direction |
| 7   | Joystick A:<br>button 2    | 8   | + 5 V                      |
| 9   | + 5 V                      | 10  | Joystick B:<br>button 1    |
| 11  | Joystick B: x<br>Direction | 12  | MIDI Out                   |
| 13  | Joystick B: y<br>Direction | 14  | Joystick B:<br>button 2    |
| 15  | MIDI In                    |     |                            |

## DMAs, IRQs AND ADDRESSES

IBM Personal Computers, compatible, and clones use DMA (Direct Memory Access) Channels, Interrupts (IRQs), and I/O Addresses in conjunction with installed expansion boards, such as the miroMEDIA Online PnP. These components are used to exchange information between the expansion board and computer memory.

Each type of computer has a finite number of these components, and only one component can be assigned to any given expansion board (or, device). If two devices are assigned to use the same component, a conflict occurs which normally prevents a device from operating correctly—or operating at all.

The tables in this appendix indicate common assignments of DMAs, IRQs, and I/O Addresses for conventionally configured computer systems. Your system will probably be configured differently due to other devices being already installed. However, the tables might be of use to you in determining how best to configure your miroMEDIA Online PnP. A chart is also provided to help you keep track of assignments in your particular computer system.

### DMA channel

Your computer and your miroMEDIA Online PnP use special channels through which they exchange information. These are known as DMA (Direct Memory Access) channels. These channels allow your miroMEDIA Online PnP (and other external devices) to directly access your computer's memory, rather than going through the CPU. Bypassing the CPU in this manner significantly improves system performance.

The following table shows normal DMA assignments for most MS-DOS-compatible computers.

| DMA Channel | Assignment              |
|-------------|-------------------------|
| 0           | not used                |
| 1           | not used                |
| 2           | floppy disk controller  |
| 3           | restricted availability |
| 4           | RAM Controller          |
| 5           | not used                |
| 6           | not used                |
| 7           | not used                |

## Interrupts (IRQs)

Your computer and miroMEDIA Online PnP use a technique called interrupt request (IRQ) to communicate. For example, your miroMEDIA Online PnP sends an interrupt request to your computer (to gain its attention) when it is ready to send or receive data through its assigned DMA channel. The following table shows the devices normally assigned to specific interrupts.

| IRQ Number | Device                                                         | Interrupt Number |
|------------|----------------------------------------------------------------|------------------|
| 0          | System Timer                                                   | 08h              |
| 1          | Keyboard                                                       | 09h              |
| 2          | EGA/VGA Boards:<br>Connection to the second<br>8259A component | 0Ah              |
| 3          | COM2/COM4<br>(serial interface)                                | 0Bh              |
| 4          | COM1/COM3<br>(serial interface)                                | 0Ch              |
| 5          | LPT2 (parallel interface)                                      | 0Dh              |
| 6          | Floppy Drive Controller                                        | 0Eh              |
| 7          | LPT1 (parallel interface)                                      | 0Fh              |
| 8          | Real-time Clock                                                | 70h              |
| 9          | Diverted IRQ2                                                  | 71h              |
| 10         | available                                                      | 72h              |
| 11         | available                                                      | 73h              |
| 12         | normally available<br>(provided PS/2 mouse not in use)         | 74h              |
| 13         | Math Coprocessor                                               | 75h              |
| 14         | Hard Disk Controller                                           | 76h              |
| 15         | 2nd IDE-Controller                                             | 77h              |

## I/O addresses

The following table shows I/O addresses as configured in conventional computers.

| Device                            | I/O Addr       |
|-----------------------------------|----------------|
| Internal system use               | 0000h to 00FFh |
| Hard Disk Controller              | 01F0h          |
| Joystick Port                     | 0200h          |
| Sound Boards                      | 0220h          |
| LPT2 (if installed)               | 0278h          |
| COM4 (if installed)               | 02E8h          |
| COM2 (if installed)               | 02F8h          |
| CD-ROM interface, video digitizer | 0300h          |
| Network Boards                    | 0360h          |
| LPT1                              | 0378h          |
| LPT3 (if installed)               | 03BCh          |
| COM3 (if installed)               | 03E8h          |
| Floppy Disk Controller            | 03F0h          |
| COM1                              | 03F8h          |

In most cases, between 4 and 32 bytes are occupied from the specified addresses.

## miroMEDIA Online PnP Ressources

The miroMEDIA Online PnP can use the following system ressources:

| Device                 | DMA              | IRQ                              | Address                       | Number              |
|------------------------|------------------|----------------------------------|-------------------------------|---------------------|
| DSP                    | 0, 1, 2, 3, 6, 7 | 3, 4, 5, 6, 7, 9, 10, 11, 14, 15 | 140 - 1F0                     | –                   |
| COM Port<br>Modem/Fax  | –                | 3, 4, 5, 9, 10, 11               | –                             | 1, 2, 3, 4, disable |
| General MIDI           | –                | 3, 5, 7, 9, 10, 11, 15           | 300, 330                      | –                   |
| Sound blaster          | 0, 1, 3          | 3, 5, 7, 9, 10, 11, 15           | 220, 240                      | –                   |
| Joystick               | –                | –                                | 201                           | –                   |
| optional: RDS<br>Radio | –                | –                                | 16 Byte in range of 110 - 3F0 | –                   |

## Chart your system settings

As mentioned earlier, if you have any problems using your miroMEDIA Online PnP, the cause is most often conflicting IRQ and/or DMA assignments. The following chart is provided to help you keep track of these assignments in your own Computer system. We recommend you maintain this chart and keep it up-to-date as a way to avoid conflicts.

| Device        | DMA | IRQ | Address |
|---------------|-----|-----|---------|
| Mwave System  |     |     |         |
| Modem/Fax     | —   |     |         |
| General MIDI  | —   | —   |         |
| Sound Blaster |     |     |         |
| Joystick      | —   | —   |         |

# AT COMMANDS

## Command mode vs. on-line state

AT commands are strings of characters that control the modem's actions. When you have started the modem by double clicking the corresponding icon, it is in command mode, i.e. it is capable of receiving commands.

When the D (Dial) or A (Answer) command has been entered, the modem is in the on-line state. When in this state, all characters sent to the modem are transmitted to the computer at the other end of the line.

The modem returns from the on-line state to command mode when a connection is broken. This is the case whenever one of the communication partners hangs up. If you want to send AT commands despite being in the on-line state, enter the characters +++ at the end of the command string. The modem responds with OK and you can enter the AT commands. The connection remains intact. To return to the on-line state, enter ATO.

## Syntax of AT commands

Each command line is prefixed by AT. Be sure to enter either AT or at. Mixed notation is invalid. The +++ command is an exception to this rule.

If no parameters are specified for a command that can be used with various parameters, the 0 will be assumed automatically.

Example:

**AT X<↵>** corresponds to **AT X0<↵>**.

## Conventions of the AT command overview

The following conventions apply in the AT command overview:

... can be replaced by any valid command or any command string.

The syntax appears in a different font. Example: AT...Bn...

n stands for a numeric value.



The Enter key (<↵>) must be pressed after every command.

## The AT Commands

| Function | Description     | Syntax                                                                                                                                            | Param.                                                                                 | Param. Description                                                                                                                                                                                                                                                                                                                                                                                        |
|----------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>A</b> | Answer          | The A command causes the Mwave Modem to begin the answer process.                                                                                 | <b>AT...A</b>                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>B</b> | Standard        | Selects the communication standard used by the Mwave Modem at 1200 bps or below.                                                                  | <b>AT...Bn...</b>                                                                      | n=0 CCITT standard<br>n=1 Bell standard                                                                                                                                                                                                                                                                                                                                                                   |
| <b>C</b> | Carrier Control | The C command enables the transmit carrier.                                                                                                       | <b>AT...C1...[CR]</b>                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>D</b> | Dial            | The modem dials a number and tries to establish a connection.                                                                                     | <b>AT...D</b><br><b>{Dig./param.}</b><br><br><b>AT...D</b><br><b>{Dig./param.};...</b> | 0-9; Numeric dialing digits<br>#, * Special dialing digits<br>P Pulse dial<br>R Force answer mode<br>S=n Dial stored number n, where n=0-3)<br>T DTMF dial<br>W Wait for dial tone<br>, Wait for time specified in register S8<br>! Perform hook flash.<br>@ Wait for quiet answer.<br>; Return to command state                                                                                          |
| <b>E</b> | Echo            | Turns the command echoing On and OFF.                                                                                                             | <b>AT...En...</b>                                                                      | n=0 Turns command echoing off.<br>n=1 Turns command echoing on.                                                                                                                                                                                                                                                                                                                                           |
| <b>F</b> | On-line Echo    | The F command is used by some modems to determine whether characters are echoed to the DTE (i.e. the PC) while the modem is in the on-line state. | <b>AT...F1...</b>                                                                      | n=0 On-line character echo enabled. Not supported, returns "ERROR".<br>n=1 On-line character echo disabled.                                                                                                                                                                                                                                                                                               |
| <b>H</b> | Hook control    |                                                                                                                                                   | <b>AT...Hn...AT...</b>                                                                 | n=0 Places the line on-hook (hangs up) and causes a transition to the off-line command state.                                                                                                                                                                                                                                                                                                             |
| <b>I</b> | Info Request    | The I command presents modem identification information.                                                                                          | <b>AT...In...</b>                                                                      | n=0 Returns: "Mwave Modem x.xx" where "x.xx" is the version of the modem.<br>n=1 Returns: "OK".<br>n=2 Verifies that the correct modem files are installed.<br>Returns "OK" if all file versions are correct. Returns the names of the incorrect file(s) if any are incorrect<br>n=3 Returns the version number of the installed modem files.<br>n=4 Returns the modem capabilities string GENERIC Mwave. |
| <b>L</b> | Speaker Volume  | The L command controls the volume of the speaker output.                                                                                          | <b>AT...Ln...</b>                                                                      | n=0 Sets the speaker volume to the minimum level.<br>n=1 Sets the speaker volume to a low level.<br>n=2 Sets the speaker volume to a medium level.<br>n=3 Sets the speaker level to a high level.                                                                                                                                                                                                         |
| <b>M</b> | Speaker Control | The M command controls the operation of the speaker.                                                                                              | <b>AT...Mn...</b>                                                                      | n=0 Sets the speaker off.<br>n=1 Sets the speaker on until the data carrier is present during the hand shaking mode. Then it is turned off.<br>n=2 Sets the speaker always on.<br>n=3 Sets the speaker off during dialing and then on until the data carrier is detected.                                                                                                                                 |
| <b>O</b> | On-line         | The O command causes the modem to return to the on-line state for a previously established connection.                                            | <b>AT...On</b>                                                                         | n=0 Causes the modem to return to the on-line state.                                                                                                                                                                                                                                                                                                                                                      |
| <b>P</b> | Pulse Dial      | The P command causes the modem to use pulse dialing for all subsequent numbers.                                                                   | <b>AT...P</b>                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Q</b> | Quiet           | The Q command controls the result codes generated by the modem.                                                                                   | <b>AT...Qn...</b>                                                                      | n=0 Enables result codes.<br>n=1 Disables result codes.                                                                                                                                                                                                                                                                                                                                                   |

| Function      | Description              | Syntax                                                                                                                                                                                                                                                                    | Param.                                   | Param. Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>S</b>      | Select Register          | The S command selects one of the modem internal registers for future operations (also see the »S-Register Settings«, the »=« and the »?« command.                                                                                                                         | <b>AT...S...</b><br><b>AT...Sn...</b>    | n=0-29 If n is omitted, then 0 is assumed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>T</b>      | Tone Diall               | The T command causes the modem to use DTMF (tone) dialing for all subsequent numbers.                                                                                                                                                                                     | <b>AT...T</b>                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>V</b>      | Verbose Response         | The V command controls the display of result codes.                                                                                                                                                                                                                       | <b>AT...Vn...</b>                        | n=0 Result codes are returned as digits.<br>n=1 Result codes are returned as text messages.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>X</b>      | Extended Results         | The X command enables the call progress tone detection capabilities and effects the associated result codes.                                                                                                                                                              | <b>AT...Xn...</b>                        | n=0 Busy and dial tone detection are disabled. Result codes 0-4 are enabled.<br>n=1 Busy and dial tone detection are disabled. Result codes 0-4, and line speed reporting via the "CONNECT xxxx" messages are enabled. Busy detection is disabled.<br>n=2 Dial tone detection is enabled. Result codes 0-4, and line speed reporting via the "CONNECT xxxx" messages are enabled. Busy detection is disabled.<br>n=3 Dial tone detection is disabled. Result codes 0-4, and line speed reporting via the "CONNECT xxxx" messages are enabled. Busy and dial tone detection are enabled. Result codes 0-4, and line speed reporting via the "CONNECT xxxx" messages are enabled.<br>n=4 |
| <b>Y</b>      | Space Disconnect         | The Y command controls the long-space disconnect capabilities of the modem. If enabled, when a continuous BREAK of at least 1.6 seconds is received, disconnect from line. When ATH0 command is received or DTR goes low, generate a 4-second BREAK before going on-hook. | <b>AT...Yn</b>                           | n=0 Disables the long-space disconnect feature.<br>n=1 Enables the long-space disconnect feature.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Z</b>      | Software Reset           | The Z command causes the modem to reload a stored profile.                                                                                                                                                                                                                |                                          | n=1 Recall stored profile 0.<br>n=2 Recall stored profile 1.<br>n=3 Recall factory defaults.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>,</b>      | Wait                     | The comma command causes the modem to wait for the time specified by the contents of register S8 in seconds before processing any more characters in the command buffer.                                                                                                  | <b>AT...,...</b>                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>=</b>      | Set Register             | The = command is used to set the value of the modem's internal registers (S0-S28). The = command is usually coupled with the Sn command.                                                                                                                                  | <b>AT...Sn=x...</b><br><b>AT...=x...</b> | n=0-28<br>x=0-255                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>&amp;D</b> | DTR Options              | The &D command controls the modem's to the DTR (Data Terminal Ready) control bit.                                                                                                                                                                                         | <b>AT...&amp;Dn...</b>                   | n=0 Ignores DTR.<br>n=1 Return to command state when ON-to-OFF transition is detected on DTR. Hang-up, disable auto-answer, and return to command state when ON-to-OFF transition is detected on DTR.<br>n=2 Perform a software reset when ON-to-OFF reansion is detected on DTR, and loads the profile as specified in &Y.<br>n=3                                                                                                                                                                                                                                                                                                                                                     |
| <b>&amp;F</b> | Factory Defaults Command | Loads the factory defaults into the internal registers.                                                                                                                                                                                                                   | <b>AT...&amp;F...</b>                    | Factory defaults.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>&amp;G</b> | Guard Tone               | Controls the guard tone selection for the V.22bis datapump.                                                                                                                                                                                                               | <b>AT...&amp;Gn...</b>                   | n=0 Disables the V.22bis guard tones.<br>n=2 Enables the 1800 Hz V.22bis guard tone.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

|               | Function                                    | Description                                                                                                                                                                                                                                                                                                                                  | Syntax                 | Param.                                 | Param. Description                                                                                                                                                                                                                                                                                                                                   |
|---------------|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>&amp;L</b> | Leased Line Mode                            | The Mwave Modem is designed to work only on the public switched telephone network. Support for leased line operation is not provided.                                                                                                                                                                                                        | <b>AT...&amp;Ln...</b> | n=0                                    | Selects switched-network line mode.                                                                                                                                                                                                                                                                                                                  |
| <b>&amp;K</b> | Set DTE Flow Control                        | The &K command selects the flow control method that your Mwave modem provides to your DTE to prevent applications from losing data in the case that the application cannot extract data from the modem as fast as it is being transmitted by the remote end of the communications link.<br>Note: The &K command is mapped to the \Q command. | <b>AT...&amp;Kn</b>    | n=0<br>n=1<br>n=2<br>n=3<br>n=4<br>n=5 | Flow Control Disabled.<br>Enables RTS/CTS hardware flow control.<br>Reserved<br>Enables RTS/CTS hardware flow control.<br>Enables XON/XOFF software flow control.<br>Enables transparent XON/XOFF software flow control.                                                                                                                             |
| <b>&amp;M</b> | Comm Mode                                   | Selects the communications mode. For this modem, only asynchronous mode is supported.                                                                                                                                                                                                                                                        | <b>AT...&amp;Mn...</b> | n=0                                    | Selects asynchronous communications.                                                                                                                                                                                                                                                                                                                 |
| <b>&amp;N</b> | Force Speed                                 | Selects the force speed mode. This command only applies to the V.32 and V.32bis modem. This command will force the modem to only connect at the speed specified in the S28 register.                                                                                                                                                         | <b>AT...&amp;Nn...</b> | n=0<br>n=1                             | Support maximum allowable rate<br>The modem selects the maximum allowable rate specified by the S28 register.<br>If S28 = 0, then the modem will connect at the speed specified by the UART port speed (set by the application program).<br>If S28 ≠ 0, then the modem will connect at the rate as specified in the description of the S28 register. |
| <b>&amp;P</b> | Pulse Ratio                                 | The &P commands is present for compatibility purposes. It does not change the make/break ratios.                                                                                                                                                                                                                                             | <b>AT...&amp;Pn...</b> | n=0<br>n=1                             | Returns "OK", but has no effect on timings.<br>Returns "OK", but has no effect on timings.                                                                                                                                                                                                                                                           |
| <b>&amp;Q</b> | Comm Mode                                   | Selects the communications mode. For this modem, only asynchronous mode is supported.                                                                                                                                                                                                                                                        | <b>AT...&amp;Qn...</b> | n=0                                    | Selects asynchronous communications.                                                                                                                                                                                                                                                                                                                 |
| <b>&amp;S</b> | DSR Options                                 | Controls the operation of the DSR status bit. The DSR status bit is found in the UART modem status register.                                                                                                                                                                                                                                 | <b>AT...&amp;Sn...</b> | n=0<br>n=1                             | DSR is always ON while the modem is loaded.<br>DSR is turned on just after handshaking is completed and turned off when the hangup process is started.                                                                                                                                                                                               |
| <b>&amp;U</b> | Enable Trellis Coding                       | Enables or disables the trellis coded data scheme in the V.32 and V.32bis modems. If issued while on-line command state, it does not take effect until the next connection is established.                                                                                                                                                   | <b>AT...&amp;Un...</b> | n=0<br>n=1                             | Enable Trellis coding in V.32/V.32bis.<br>Disable Trellis coding in V.32/V.32bis.                                                                                                                                                                                                                                                                    |
| <b>&amp;V</b> | View Active Configuration and User Profiles | Displays active & stored profiles and stored telephone numbers. Inputs from the DTE are ignored while the view information is being sent to the DTE.                                                                                                                                                                                         | <b>AT...&amp;Vn...</b> |                                        |                                                                                                                                                                                                                                                                                                                                                      |
| <b>&amp;W</b> | Write Configuration                         | Saves the active modem configuration. The following registers are saved in nonvolatile storage: S0, S2-S12, S14, S18, S21-S23, S25, S27, S28.<br>In addition, the following command parameters are stored: \A, \K, \L, \N, \T, %A, %C, "Hn, "Nn, On. The initial value of each of these profiles is defined by the &F command.               | <b>AT...&amp;Wn...</b> | n=0<br>n=1                             | Store profile 0.<br>Store profile 1.                                                                                                                                                                                                                                                                                                                 |
| <b>&amp;Y</b> | Select Stored Profile on Power up Option    | Determines which stored profile is established upon modem power up.                                                                                                                                                                                                                                                                          | <b>AT...&amp;Yn...</b> | n=0<br>n=1<br>n=2                      | Select stored profile 0 on power up.<br>Select stored profile 1 on power up.<br>Select factory defaults on power up.                                                                                                                                                                                                                                 |

| Function      | Description            | Syntax                                                                                                                                                                                                                                                                                                                                                                                                                             | Param.                                                                                    | Param. Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>&amp;Z</b> | Store Number           | Saves up to four separate phone numbers (dial strings) to permanent storage. The &Z command may be followed by the dial string (36 characters max) or by the identifier (0-3) for the phone number to save. This command may not be followed by additional commands.                                                                                                                                                               | <b>AT...Z</b><br><b>{dig./param.)}</b><br><br><b>AT...Zn=</b><br><b>{dig./param.);...</b> | 0-9;<br>#, *<br><br>P<br>R<br>T<br>W<br><br>,<br>!<br><br>@<br><br>;<br>Numeric dialing digits:<br><br>Pulse dial<br>Force answer mode. Must be entered as the last character.<br>DTMF dial<br>Wait for dial tone. Wait for time specified in register S8.<br>Hook flash; the modem switches itself off for 90 ms (e. g. expedient for forwarding telephone calls in telephone systems.)<br>Modem waits for 5 seconds (quiet answer).<br>Return to command state after number is dialed.                                                                                                                                                                                                                                                                                                                                                             |
| <b>A</b>      | Maximum MNP Block Size | The \A extended command sets the maximum MNP stream mode block size to be used by the modem during an MNP session.                                                                                                                                                                                                                                                                                                                 | <b>AT...\An...</b>                                                                        | n=0<br>n=1<br>n=2<br>n=3<br>n=4<br>max. block size of 64 bytes<br>max. block size of 128 bytes<br>max. block size of 192 bytes<br>max. block size of 256 bytes variable<br>block size                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>B</b>      | Send Break             | Causes the modem to transmit a break signal. This command is valid only in on-line command mode.                                                                                                                                                                                                                                                                                                                                   | <b>AT...\B...</b>                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>K</b>      | Break Control          | This command controls the actions to be taken by the Mwave Modem upon reception of a break signal from either the DTE or remote modem. The DTE may generate a break either through the UART hardware or by using the \B command. Parameters 1-3 generate identical behavior for a non-ECL connection. The default is \K3.                                                                                                          | <b>AT...\Kn...</b>                                                                        | n=0<br><br><br><br><br><br><br><br><br><br>n=1<br>n=2<br><br><br>n=3<br>When a break is received from the DTE and the modem is online, the modem escapes to command mode but a break is not sent to the the remote modem. When a break is received from the remote modem, it is reported immediately and is nondestructive to any buffered data.<br>Breaks cause destruction of any buffered data, and they are reported immediately. The escaped state is not entered when a break is received from the DTE.<br>Breaks are nondestructive, and the break is reported immediately. The escaped state is not entered when a break is received from the DTE.<br>Breaks are nondestructive, and the break is queued in sequence with any buffered data and is reported in turn. The escaped state is not entered when a break is received from the DTE. |
| <b>L</b>      | MNP Data Mode          | Selects the MNP and V.42/V.42bis operational behavior. Whenever an Error Corrected Link is established, the session will attempt to also get a compressed link if possible. A V.42bis compressed link will be attempted first. If that fails or if a "H0 command" has been issued, then an MNP5 compressed link will be attempted. If that fails or if a "%C0 command" has been issued, a non-compressed link will be established. | <b>AT...\Ln...</b>                                                                        | n=1<br>n=2<br>variable mode<br>block mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>L</b>      | MNP Data Mode          | Selects the MNP and V.42/V.42bis operational behavior. Whenever an Error Corrected Link is established, the session will attempt to also get a compressed link if possible. A V.42bis compressed link will be attempted first. If that fails or if a "H0 command" has been issued, then an MNP5 compressed link will be attempted. If that fails or if a "%C0 command" has been issued, a non-compressed link will be established. | <b>AT...\Ln...</b>                                                                        | n=1<br>n=2<br>variable mode<br>block mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

| Function  | Description                     | Syntax                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Param.              | Param. Description                                                                                                                                                     |
|-----------|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>T</b>  | Set Timer                       | Controls the operation of the inactivity timer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <b>AT...\Tn...</b>  | n=0 The timer is disabled.<br>n=1-90 The timer is set to 1 - 90 minutes.                                                                                               |
| <b>V</b>  | MNP Result Codes                | Sets the MNP result codes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <b>AT...\Vn...</b>  | n=0 Disables MNP result codes.<br>n=1 Enables MNP result codes.                                                                                                        |
| <b>%A</b> | Auto Fallback Character         | The %A extended command defines a character to be used to abort the MNP** negotiation process. The auto fallback character is a 7-bit character with no parity. The auto fallback character should not be set to the ASCII SYN character (decimal 22). This causes the MNP negotiation to be aborted for valid MNP frames. The default is %A0, which disables the auto fallback feature.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <b>AT...%C n...</b> | n=0 No data compression.<br>n=1 Data compression is enabled for MNP class five.                                                                                        |
| <b>%E</b> | Fast Rate Renegotiation Control | The %E command controls the modem's response to a change in line quality and to requests for retrain or fallback/fall forward by the other end. This command only affects V.32 and V.32bis. When %E2 is active, the modem monitors the line quality. When line quality is insufficient to sustain the current connect speed, the modem will initiate a rate renegotiation to a lower speed within the V.32bis/V.32 modulation speeds (4800, 7200, 9600, 12000 and 14400 bps). The modem will keep falling back as needed until the speed reaches 4800 bps. If the line quality deteriorates further while connected at 4800 bps, the modems will hangup the telephone line. If the quality of the line increases, the modem will initiate a rate renegotiation to a higher speed if the modem currently has a V.32bis connection with the modem at the other end of the phone line. The rate renegotiation will be done without a retrain in this case. The modem will not increase the line speed if the modem is connected via V.32 to the other end of the phone line. Fall forward via Fast Rate Renegotiation is not supported in the V.32 specification. | <b>AT...%E n...</b> | n=0 Disable Auto-Retrain and Fast Rate Renegotiation.<br>n=1 Enable Auto-Retrain.<br>n=2 Enable Fast Rate Renegotiation and Auto-Retrain                               |
| <b>H</b>  | V.42bis Compression Control     | The "H extended command controls the data compression to be negotiated for with V.42bis. This command may be issued at anytime but will only take effect on the next connection.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <b>AT..."H n...</b> | n=0 V.42bis Disabled<br>n=1 V.42bis enabled for transmission only<br>n=2 V.42bis enabled for reception only<br>n=3 V.42bis enabled for both transmission and reception |
| <b>N</b>  | V.42bis Dictionary Size         | The "N extended command controls the dictionary size to be negotiated for with V.42bis. This command may be issued at anytime, but will take effect only on the next connection.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <b>AT..."N n...</b> | n=0 512 Entries<br>n=1 1024 Entries<br>n=2 2048 Entries                                                                                                                |

| Function   | Description                        | Syntax                                                                                                                                                                                                                                                                                                                                                                   | Param.                                                                           | Param. Description                                                                                                                                                                                                                                                                    |
|------------|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>O</b>   | V.42bis Maximum String Length      | The "O extended command controls the maximum string length to be negotiated for with V.42bis. This command may be issued at anytime, but will take effect only on the next connection.                                                                                                                                                                                   | <b>AT... "O n...</b>                                                             | n=0, 32 character maximum string length<br>n= 6... 6 to 250 character maximum string length<br>250                                                                                                                                                                                    |
| <b>SS</b>  | DSVD                               | The -SSE command controls the Mwave Digital Simultaneous Voice over Data (DSVD) function. When this function is enabled, a call is placed (via ATDT) to another Mwave Modem that is also enabled for Mwave DSVD, and a connection is established, the users can talk to each other over their microphone and speakers while still maintaining their normal data traffic. | <b>AT...-SSE[=] n...</b>                                                         | n=0, 32 Disable Mwave DSVD<br>n= 6... Enable Mwave DSVD<br>250                                                                                                                                                                                                                        |
| <b>%T</b>  |                                    | <b>AT...%TT6 R, S, C, P...</b><br>R must be between 0 and B (hexidecimal value).<br>S must 0, 3, or 4. All other values are invalid.<br>A is the auxilliary channel option. It is not yet supported. Any value is ignored.<br>P is the pre-emphasis index. Valid values are 0 to A hexidecimal.                                                                          | R=0<br>R=1<br>R=2<br>R=3<br>R=4<br>R=5<br>R=6<br>R=7<br>R=8<br>R=9<br>R=A<br>R=B | 2400 bps (may not be selected unless S=0)<br>4800 bps<br>7200 bps<br>9600 bps<br>12000 bps<br>14400 bps<br>16800 bps<br>19200 bps<br>21600 bps<br>24000 bps (may not be selected if S=0)<br>26400 bps (may not be selected if S=0)<br>B 28800 bps (may not be selected if S=0 or S=3) |
|            |                                    |                                                                                                                                                                                                                                                                                                                                                                          | S=0<br>S=3<br>S=4                                                                | 2400 symbols per second<br>3000 symbols per second<br>3200 symbols per second                                                                                                                                                                                                         |
|            |                                    |                                                                                                                                                                                                                                                                                                                                                                          | C<=0<br>C>0                                                                      | Select V.34 low carrier<br>Select V.34 high carrier                                                                                                                                                                                                                                   |
| <b>+MS</b> | Select Modulation                  | The +MS command specifies the modulation to use in originating or answering a connection.                                                                                                                                                                                                                                                                                | <b>AT...+MS=n</b>                                                                | n=3 V.23<br>n=11 V.34                                                                                                                                                                                                                                                                 |
| <b>SS</b>  | Mwave Simultaneous Voice over Data | The -SSE command controls the Mwave Digital Simultaneous Voice over Data (DSVD) function. When this function is enabled, a call is placed (via ATDT) to another Mwave Modem that is also enabled for Mwave DSVD, and a connection is established, the users can talk to each other over their microphone and speakers while still maintaining their normal data traffic. | <b>AT...-SSE[=]n</b>                                                             | n=0 Disable Mwave DSVD<br>n=1 Enable Mwave DSVD                                                                                                                                                                                                                                       |

|            | Function                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Syntax            | Param. | Param. Description |
|------------|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|--------|--------------------|
| <b>*TH</b> | Data Rate Aggressiveness | <p>The *TH command can be used to adjust the aggressiveness of the V.34 data rate. The normal default setting is 4. The higher the value of n, the less aggressive the Mwave V.34 modem will be to select the data rate. *TH8 sets the threshold 4 dB higher for the signal-to-noise ratio (SNR) for the same bit rate to be used. If you experience difficulty connecting, you may want to set n to a higher value to select a less aggressive setting than the default of *TH4. A higher value tends to make connections at a lower data rate unless the SNR is high enough.</p> | <b>AT *THn...</b> |        |                    |

## S REGISTERS

The following table contains a summary of the S registers with their defaults, possible values and units.

| S-Register | Default | Range  | Units           | Description                                                                                                                                                                                                                                                                                                                          |
|------------|---------|--------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S0         | 0       | 0-5    | Number of rings | This register contains an integer representing the number of rings to allow before going off-hook. When S0 contains a non-zero value, the Modem DSP software is in auto answer mode.                                                                                                                                                 |
| S1         | 0       | 0-255  | Number of rings | This register contains the ring count.                                                                                                                                                                                                                                                                                               |
| S2         | 43      | 0-255  | ASCII character | S2 contains the ASCII code for the escape character. If S2 contains a value greater than 127, then the escape sequence (+++) is disabled. The default is the "+" character.                                                                                                                                                          |
| S3         | 13      | 0-127  | ASCII character | Contains the ASCII code for the carriage return.                                                                                                                                                                                                                                                                                     |
| S4         | 10      | 0-127  | ASCII character | Contains the ASCII code for the line feed.                                                                                                                                                                                                                                                                                           |
| S5         | 10      | 0-127  | ASCII character | Contains the ASCII code for the backspace key.                                                                                                                                                                                                                                                                                       |
| S6         | 2       | 3-5    | Seconds         | S6 contains the amount of time to wait (in seconds) after going off-hook, before dialing.                                                                                                                                                                                                                                            |
| S7         | 30      | 0-58   | Seconds         | S7 contains the amount of time to wait for a data carrier in seconds. If a carrier is detected, a CONNECT result is returned, otherwise a NO CARRIER result occurs.                                                                                                                                                                  |
| S8         | 2       | 0-255  | Seconds         | Contains the amount of time to wait for a comma command or dial modifier.                                                                                                                                                                                                                                                            |
| S9         | 6       | 1-255  | 1/10 seconds    | S9 contains the amount of time to wait between a return of the carrier in the on-line state and the acceptance of the carriers.                                                                                                                                                                                                      |
| S10        | 14      | 0-65   | 1/10 seconds    | S10 contains the amount of time to wait between loss of the carrier and hang-up.                                                                                                                                                                                                                                                     |
| S11        | 95      | 50-255 | Milli seconds   | Contains the duration (ms) and inter-digit delay for DTMF tone dialing.                                                                                                                                                                                                                                                              |
| S12        | 50      | 0-255  | 1/50 seconds    | Contains the guard time delay for recognition of the escape sequence (+++).                                                                                                                                                                                                                                                          |
| S24        | 0       | 0-1    |                 | S24 enables/disables modem calling tone. ATS24=1 enables tone, ATS24=0 disables tone. Enabling calling tone may make it easier for the modem you are calling to detect that this is a data call if the remote modem uses a voice/data/fax discriminator.                                                                             |
| S25        | 5       | 0-255  | 1/10 seconds    | S25 specifies the delay time threshold for which DTR must be active in order to be recognised. If DTR remains at a state for less than 25 seconds, it is ignored.                                                                                                                                                                    |
| S30\T      | 0       | 0-540  |                 | S30\T sets the length of time, in tens of seconds, that the modem remains connected when no data is sent or received. The time resets when data is transmitted. In error-correcting mode, received data also resets the timer.                                                                                                       |
| S28        | 0       | 0-12   | –               | Contains the user's desired line connection speed. The connection speed will be the maximum speed supported by both modems not exceeding the speed specified by this register.                                                                                                                                                       |
| S32        | 17      | 0-255  |                 | S32 sets the value of the XON character.                                                                                                                                                                                                                                                                                             |
| S33        | 19      | 0-255  |                 | S33 sets the value of the XOFF character.                                                                                                                                                                                                                                                                                            |
| S49        |         |        |                 | The S49 values are bit-mapped to the S49 register.<br>Value Description<br>01 Bit 0 - Reserved.<br>02 Bit 1 - Disables call indicator.<br>04 Bit 2 - Disables V.8 protocol.<br>08 Bit 3 - Disables V.34 protocol.<br>These values are additive. For example, setting S49=7 disables call indicator, V.8 protocol, and V.34 protocol. |

| S-Register | Default | Range | Units | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------|---------|-------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S50        | 0       |       |       | <p>By setting various bits in the S50 register, you can disable some or all of the "symbol rates" or "baud rate" (which is different than a bit rate) that the V.34 modem will request for reception. Only the receiving modem can disable transmit symbol rates.</p> <p>The S50 values are bit-mapped to the S50 register.</p> <p>01 Bit 0 - Disables 2400 baud receive symbol rate.<br/> 02 Bit 1 - Disables 2743 baud receive symbol rate.<br/> 04 Bit 2 - Disables 2800 baud receive symbol rate.<br/> 08 Bit 3 - Disables 3000 baud receive symbol rate.<br/> 16 Bit 4 - Disables 3200 baud receive symbol rate.<br/> 32 Bit 5 - Disables 3429 baud receive symbol rate.<br/> 64 Bit 6 - Disables asymmetric symbol rates.<br/> 128 Bit 7 - Reserved.</p> <p>These values are additive. For example, setting S50=7 disables 2400, 2743, and 2800 baud symbol rates.</p> |
| S52        | 2       |       |       | <p>S52 controls various features of the V.34 data pump.</p> <p>The S52 values are bit-mapped to the S52 register. Value Bit Description</p> <p>01 Bit 0 - Disable asymmetric data rates for V.34.<br/> 02 Bit 1 - Disable auxiliary channel for V.34.<br/> Bits 2-7 - Reserved</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| S53        | 0       |       |       | <p>01 Bit 0 - Reserved<br/> 02 Bit 1 - Disable requests for pre-emphasis (receive).<br/> 04 Bit 2 - Disable requests for constellation warping (receive).<br/> 08 Bit 3 - Disable requests for constellation shaping (receive).<br/> 16 Bit 4 - Disable requests for precoding (receive).<br/> Bits 5-7 - Reserved</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Parameters for S28:

| Param. | Description                                    |
|--------|------------------------------------------------|
| 00     | UART setting                                   |
| 01     | 50 bps connection; Bell 103/V.21 protocol      |
| 02     | 75 bps connection; Bell 103/V.21 protocol      |
| 03     | 110 bps connection; Bell 103/V.21 protocol     |
| 04     | 134.5 bps connection; Bell 103/V.21 protocol   |
| 05     | 150 bps connection; Bell 103/V.21 protocol     |
| 06     | 300 bps connection; Bell 103/V.21 protocol     |
| 07     | Reserved                                       |
| 08     | 1200 bps connection; V.22bis/Bell-212 protocol |
| 09     | 2400 bps connection; V.22bis protocol          |
| 10     | 4800 bps connection; V.32/V.32bis protocol     |
| 11     | 7200 bps connection; V.32bis protocol          |
| 12     | 9600 bps connection; V.32/V.32bis protocol     |
| 13     | 12000 bps connection; V.32bis protocol         |
| 14     | 14400 bps connection; V.32bis protocol         |

# MODEM MESSAGES

| No. | Text                | Explanation                                                                                                                                                                               |
|-----|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0   | OK                  | Acknowledges the execution of a command.                                                                                                                                                  |
| 1   | CONNECT             | Indicates that a connection has been established with a remote modem at a speed of 0-300 bps.                                                                                             |
| 2   | RING                | Indicates that an incoming call has been detected.                                                                                                                                        |
| 3   | NO CARRIER          | Indicates a failure to connect (handshake state) or a loss of carrier (on-line state).                                                                                                    |
| 4   | ERROR               | Error. Possible causes: Invalid command or command line too long.                                                                                                                         |
| 5   | CONNECT 1200        | Indicates that a connection has been established with a remote modem at a speed of 1200 bps.                                                                                              |
| 6   | NO DIALTONE         | Indicates that dial tone detection was attempted but not recognized. Enabled by X2 and X4.                                                                                                |
| 7   | BUSY                | Indicates that a busy signal was detected during the call establishment. Enabled by X2 and X4.                                                                                            |
| 8   | NO ANSWER           | Indicates that the required period of silence was not detected during the "wait for quiet answer" time period specified by modem register 7. This occurs when an @ dial modifier is used. |
| 10  | CONNECT 2400        | Indicates that a connection has been established with a remote modem at a speed of 2400 bps.                                                                                              |
| 15  | HOST DRIVER TIMEOUT | Indicates that the PC is not responding to interrupts from the board.                                                                                                                     |
| 19  | CONNECT ECL         | Indicates that a connection has been established with an ECL (Error Correction Link), with data compression, using MNP.                                                                   |
| 20  | CONNECT ECLC        | Indicates that a connection has been established with an ECL (Error Correction Link) using MNP.                                                                                           |
| 25  | CONNECT 1200/ECL    | Indicates that a connection has been established with an ECL (Error Correction Link) using MNP at 1200 bps.                                                                               |
| 26  | CONNECT 1200/ECLC   | Indicates that a connection has been established with an ECL (Error Correction Link), with data compression, using MNP at 1200 bps.                                                       |
| 30  | CONNECT 2400/ECL    | see examples above                                                                                                                                                                        |
| 31  | CONNECT 2400/ECLC   | see examples above                                                                                                                                                                        |
| 32  | BLACKLISTED         | No further selection for desired numbers possible.                                                                                                                                        |
| 33  | CONNECT 4800        | see examples above                                                                                                                                                                        |
| 34  | CONNECT 4800/ECL    | see examples above                                                                                                                                                                        |
| 35  | CONNECT 4800/ECLC   | see examples above                                                                                                                                                                        |
| 37  | CONNECT 7200        | see examples above                                                                                                                                                                        |
| 38  | CONNECT 7200/ECL    | see examples above                                                                                                                                                                        |
| 39  | CONNECT 7200/ECLC   | see examples above                                                                                                                                                                        |
| 41  | CONNECT 9600/ECLC   | see examples above                                                                                                                                                                        |
| 42  | CONNECT 9600/ECL    | see examples above                                                                                                                                                                        |
| 43  | CONNECT 9600/ECLC   | see examples above                                                                                                                                                                        |
| 45  | CONNECT 12000       | see examples above                                                                                                                                                                        |
| 46  | CONNECT 12000/ECL   | see examples above                                                                                                                                                                        |
| 47  | CONNECT 12000/ECLC  | see examples above                                                                                                                                                                        |
| 49  | CONNECT 14000       | see examples above                                                                                                                                                                        |
| 50  | CONNECT 14000/ECL   | see examples above                                                                                                                                                                        |
| 51  | CONNECT 14000/ECLC  | see examples above                                                                                                                                                                        |
| 53  | CONNECT 16800       | see examples above                                                                                                                                                                        |
| 54  | CONNECT 16800/ECL   | see examples above                                                                                                                                                                        |
| 55  | CONNECT 16800/ECLC  | see examples above                                                                                                                                                                        |
| 57  | CONNECT 19200       | see examples above                                                                                                                                                                        |
| 58  | CONNECT 19200/ECL   | see examples above                                                                                                                                                                        |
| 59  | CONNECT 19200/ECLC  | see examples above                                                                                                                                                                        |
| 61  | CONNECT 21600       | see examples above                                                                                                                                                                        |
| 62  | CONNECT 21600/ECL   | see examples above                                                                                                                                                                        |
| 63  | CONNECT 21600/ECLC  | see examples above                                                                                                                                                                        |
| 64  | CONNECT 24000       | see examples above                                                                                                                                                                        |
| 65  | CONNECT 24000/ECL   | see examples above                                                                                                                                                                        |
| 66  | CONNECT 24000/ECLC  | see examples above                                                                                                                                                                        |
| 67  | CONNECT 26400       | see examples above                                                                                                                                                                        |
| 68  | CONNECT 26400/ECL   | see examples above                                                                                                                                                                        |
| 69  | CONNECT 26400/ECLC  | see examples above                                                                                                                                                                        |
| 71  | CONNECT 28800       | see examples above                                                                                                                                                                        |
| 72  | CONNECT 28800/ECL   | see examples above                                                                                                                                                                        |
| 73  | CONNECT 28800/ECLC  | see examples above                                                                                                                                                                        |

# ERROR MESSAGES

| Message         | Message Text & Description                                                                                                                                                                                                                                                                                                                           |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MWME0001</b> | <b>Mwave Modem Internal Error.</b><br>Record the information in the error dialog box and report it to the service contact listed in your installation manual.                                                                                                                                                                                        |
| <b>MWME0002</b> | <b>The Mwave phone line is already in use.</b><br>Another Mwave communications adapter application is currently using the phone line. In this case, the user needs to restart the operating environment and try again.<br><br>If the modem operation ended prematurely this error might be encountered. In this case, restart Windows and try again. |
| <b>MWME0003</b> | <b>The Mwave phone handset is already in use.</b><br>Another application is currently using the phone handset. In this case, the user needs to restart the operating environment and try again.<br><br>If the modem operation ended prematurely this error might be encountered. In this case, restart Windows and try again.                        |
| <b>MWME0004</b> | <b>The Mwave Communications port is already in use.</b><br>Another Mwave Communications adapter application is currently using the COM-port.<br><br>If the modem operation ended prematurely this error might be encountered. In this case, restart Windows and try again.                                                                           |
| <b>MWME0005</b> | <b>The Mwave DSP is overcommitted.</b><br>There are not enough resources (MIPS, Data Store, Instruction Store) available on the DSP to fulfill the request. Stop another Mwave Communications Adapter application and restart the modem.                                                                                                             |
| <b>MWME0006</b> | <b>The Mwave Modem cannot locate the needed DSP files.</b><br>Check the MWPATH environment variable in the AUTOEXEC.BAT to make sure the paths to the .DSP files are correct.                                                                                                                                                                        |
| <b>MWMI0001</b> | <b>Mwave Modem Help is not available.</b><br>The Mwave modem cannot find the MWMOS2.HLP help file.                                                                                                                                                                                                                                                   |

# GLOSSARY

The following glossary provides explanations of the most important terms used in this manual.

Cross-references are indicated by .


|                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Address</b>           | All memory locations in the computer are numbered (addressed). Each memory location can be addressed directly in this way. Some addresses are reserved for specific hardware components and must not be used otherwise. We speak of an address conflict if two hardware components use the same address.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>analog</b>            | The opposite of  digital. Analog quantities may assume any values.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>ASCII</b>             | American Standards Code for Information Interchange. ASCII character set: the standard character set used by IBM and compatible computers. The ASCII character set consists of 256 characters, of which the first 128 are defined.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>asynchronous</b>      | In an asynchronous data transfer, the data is transferred character-by-character (one character normally consists of 8 bits). The characters are embraced by control bits (start and stop bits). The control bits signal to the remote station whenever a new character is being sent and whether the last character has been sent completely.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>AT commands</b>       | Modem control command set, also referred to as the Hayes command set (  Hayes). AT commands are prefixed with AT (=attention).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Auto answer</b>       | The ability of a modem to process a call automatically after a defined number of rings.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Bell standard</b>     | Standard of the American Bell Telephone Company.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>bis</b>               | French for “two” or “second revision”.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Bit</b>               | Binary Digit. The smallest information unit of a computer. Two states “0” and “1” can be represented with one bit. Accordingly, $2^2=4$ can be represented with two bits and $2^3=8$ with three bits etc. In a computer, these two states are realised via “0 V” (no current = 0) and “5 V” (current = 1). 8 bits = 1  byte are needed to represent one character (a letter or number etc.).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>bps</b>               | Bits per second.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Bus</b>               | In a computer, buses are used for communication between the processor and the hardware installed in the computer (hard disk or a graphics board etc.). Different amounts of information can be transferred depending on the width of the bus. A 8-bit wide bus can communicate exactly 8  bits (= one  byte = one character) at one time. One byte consists of eight  bits. With one byte, precisely one character (a letter or a number etc.) can be depicted. It is coded in binary, i.e. in “zeroes” (0) and “ones” (1). According to the  ASCII character set, the character “E” is coded as “01000101” or “45h” (hexadecimal). |
| <b>Carrier</b>           | The carrier frequency that modems send. The modulated data is transmitted from one modem to another on the carrier frequency.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Carrier frequency</b> |  Carrier.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

|                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CCITT</b>                | Comité Consultatif International Télégraphique et Téléphonique. An umbrella organisation of the international telecommunications union that concerns itself with standardization of data and telephone services. The standards for data transfer through telephone networks are set out in the V. standards (e.g. V.32).                                                                                                                                                                                                                                                 |
| <b>CD-ROM</b>               | Compact Disk-Read Only Memory. A digital storage disk with a very high storage capacity that is read by a laser beam.                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Clock frequency</b>      | The speed at which the individual command sequences are run within the processor. The higher the  clock frequency is, the faster the commands run.                                                                                                                                                                                                                                                                                                                                      |
| <b>CNG tones</b>            | Connecting tones that fax devices send to identify themselves as such.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>COM interface</b>        | Another designation for the serial interfaces in a PC (also: RS232). Through the COM interfaces, data is transferred in a data line bit-by-bit (all  bits of one  byte are transferred in succession). Serial data transfer is slower than through the parallel interface, but is substantially less susceptible to interference. Multimedia interfaces are identified by COM and a digit (e.g. COM1). |
| <b>Command mode</b>         | In the command mode, the modem interprets received characters as a command (  On-line state).                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>CONFIG.SYS</b>           | A configuration file under  DOS that is run automatically when starting the system. The CONFIG.SYS file contains drivers which, among other things, control output on the monitor, use of the keyboard and of the mouse.                                                                                                                                                                                                                                                                |
| <b>CPU</b>                  | Central Processing Unit. The CPU controls essential functions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Data pump</b>            | Part of the modem's internal software that is crucial with regard to the quality and speed of a modem's data transfer capacity.                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Dedicated line</b>       | The opposite of  switched line. A dedicated line is a permanent connection between two communication partners. A dedicated line is always active.                                                                                                                                                                                                                                                                                                                                     |
| <b>Demodulation digital</b> | (Back-)conversion of analog signals to digital signals (  Modulation).<br>Literally: represented by numbers. The opposite of  analog. In data technology, characters are mostly represented by binary signals, i.e. by signals that can only assume two states ("0" and "1").                                                                                                                    |
| <b>DMA channel</b>          | By way of a D(irect)M(emory)A(ccess) channel, direct and thus very fast data transfer takes place between any hardware component (e.g. an expansion board) and the main memory, circumventing the CPU.<br>The DMA channels are numbered. One DMA channel can only be used by one hardware component at a time.                                                                                                                                                                                                                                                           |
| <b>Driver</b>               | Programs, among other things for integrating hardware (e.g. drivers for a CD-ROM drive) in the computer and for adapting the software to the hardware (e.g. drivers for a graphical user interface such as Microsoft Windows) in order to exploit the possibilities offered by expansion board.                                                                                                                                                                                                                                                                          |
| <b>DSP</b>                  | Digital signal processor. A DSP is a processor that is oriented to the tasks of digital data processing (filtering, amplification, generation of digitally coded analog signals).                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>DSR signal</b>           | The D(ata)S(et)R(eady) signal indicates that the data is ready to be sent.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

|                              |                                                                                                                                                                                                                                                                                                                                                                               |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>DTE</b>                   | Data Terminal Equipment. A device or a system unit for sending and receiving data.                                                                                                                                                                                                                                                                                            |
| <b>DTMF</b>                  | Dial Tone Multifrequency (also: tone dialling). When using DTMF, pairs of tones are sent during dialling.                                                                                                                                                                                                                                                                     |
| <b>DTR signal</b>            | The D(ata)T(erminal)R(eady) signal indicates that the modem is ready to receive.                                                                                                                                                                                                                                                                                              |
| <b>DSVD</b>                  | Digital Simultaneous Voice and Data. DSVD allows the simultaneous transmission of data and digitally encoded voice signals over a single dial-up phone connection.                                                                                                                                                                                                            |
| <b>Echo</b>                  | On the one hand, modems can send all characters received directly back to the DTE so they can be seen on the screen. On the other hand, the modem sends back all data received from a remote station. These two operations are referred to as the “Echo”.                                                                                                                     |
| <b>Error correction</b>      | Process for compensating for interferences on the telephone line. Known error correction methods are MNP5 and V.42bis.                                                                                                                                                                                                                                                        |
| <b>Fallback</b>              | Switching back to a slower data transfer rate when transmission quality is poor.                                                                                                                                                                                                                                                                                              |
| <b>Fax</b>                   | Lat.: fac simile=make equal. When faxing, image data of originals is transmitted.                                                                                                                                                                                                                                                                                             |
| <b>Full duplex operation</b> | Simultaneous transfer of data on one line in both directions, also referred to as duplex operation (📖 Half duplex operation).                                                                                                                                                                                                                                                 |
| <b>Guard Tone</b>            | Comparison tone for international connections.                                                                                                                                                                                                                                                                                                                                |
| <b>Half duplex operation</b> | Transfer of data on one line in both directions. Transfer can only take place alternately in one or the other direction, i.e. not simultaneously (📖 Full duplex operation).                                                                                                                                                                                                   |
| <b>Hands free device</b>     | A device that enables the user to talk and listen on the telephone without using the receiver.                                                                                                                                                                                                                                                                                |
| <b>Handshake phase</b>       | Before data can be sent via a connection, both modems have to define which protocols and speeds are to be used. This “negotiation phase” is also referred to as the handshake phase.                                                                                                                                                                                          |
| <b>Hayes</b>                 | An American modem manufacturer who was the first to integrate a command repertoire in modems (📖 AT commands). The Hayes commands have established themselves as the defacto standard.                                                                                                                                                                                         |
| <b>Headset</b>               | A combination of headphones and microphone that is used instead of a telephone receiver.                                                                                                                                                                                                                                                                                      |
| <b>IDE</b>                   | A general standard for the connection of a CD-ROM drive.                                                                                                                                                                                                                                                                                                                      |
| <b>Impedance</b>             | The apparent resistance of AC components.                                                                                                                                                                                                                                                                                                                                     |
| <b>Interface</b>             | The transition point between two areas of a system or between two systems where information, pulses and signals are adapted so that they can be understood at the receiving end in the same way as at the sending end. For example, signals sent from the computer to the printer have to be adapted by an interface so that the printer will “understand” how to print them. |

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Interrupt</b>                | An interrupt is a signal by means of which expansion boards and other hardware components request the CPU. Each hardware component should possess its own interrupt.                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>ISA bus</b>                  | International Standard Architecture. A bus with a 16-bit width that is capable of transferring a data rate of 8 MBytes at a clock frequency of 8 MHz.                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>KByte</b>                    | One kbyte (kilobyte) corresponds to 1024 bytes.<br>The “K” (kilo) always corresponds to the number “1024”.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Mailbox</b>                  | Computer software that is capable of receiving and sending data through one or several modems. Such a program generally runs unsupervised on a computer that has been specially reserved for this purpose (also: BBS=Bulletin Board System).                                                                                                                                                                                                                                                                                                                                 |
| <b>MByte</b>                    | One MByte (megabyte) is 1024 Kbytes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>MNP</b>                      | Microcom Networking Protocol, a data transfer process of the Microcom company. There are a total of ten MNP classes, some of which are upwardly compatible. MNP 1 to MNP 4 are pure data transfer protocols; from MNP 5 on, the data is also compressed.                                                                                                                                                                                                                                                                                                                     |
| <b>Modem</b>                    | The word “Modem” is composed of the parts “modulator” (Modulation) and “demodulator” (Demodulation). By means of modems, computers can communicate with each other through analog telephone lines. In doing so, the modem converts the electronic digital signal emitted by the sending computer to acoustic signals (modulation). The analog acoustic signals are then transmitted through the telephone line and arrive at a second modem. The receiving modem converts the analog acoustic signals back to electronic digital signals and forwards these to the computer. |
| <b>Modulation</b>               | Conversion of digital to analog signals.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Multitasking</b>             | Simultaneous execution of several functions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Mwave</b>                    | The Mwave platform is a modular architecture developed by IBM for telecommunications and sound applications.                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>On-line state</b>            | When in this state, all characters are sent from the modem to the distant station (command mode).                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Operating system</b>         | The operating system allows communication between the hardware, the software and the user. Among other things, the tasks of an operating system include file and program management.                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Pulse dialling</b>           | Pulse sequences are sent during dialling. The number 0 corresponds to ten pulse, the number 1 corresponds to one pulse and the number 2 to two pulses etc.                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Register</b>                 | A memory.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Remote (distant) station</b> | In this case: the modem with which you are communicating during a connection.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

|                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>S register</b>          | Status register: a register in which the operating parameters of a modem are stored.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Switched line</b>       | The opposite of a  dedicated line. When using a switched line, the other user must be dialled up in order to establish the connection.                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>TAPI</b>                | Telephone Application Interface. Standardized interface for telephone applications.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Tele-communications</b> | The generic term used for the information channels provided by the telephone company.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Tone dialling</b>       |  DTMF.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Trellis coding</b>      | A special coding method with error correction; only used as from V.32.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>UART</b>                | Universal Asynchronous Receiver and Transmitter: a special component for controlling an asynchronous serial interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Voice recognition</b>   | Recognition of spoken language by a computer. This has only been partly realised up to now.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>V. standards</b>        |  CCITT.<br>V.17: Half duplex data transfer at up to 14 400 bps when using fax devices.<br>V.21: Full duplex data transfer at 300 bps.<br>V.22: Full duplex data transfer at 1200 bps.<br>V.22bis: Full duplex data transfer at 2400 bps.<br>V.27ter: Half duplex data transfer at 4800 bps for fax modems.<br>V.29: Half duplex data transfer at 9600 bps for fax modems.<br>V.32: Full duplex data transfer at up to 9600 bps or fallback to 4800 bps.<br>V.32bis: Full duplex data transfer at a data transfer rate of 14400 bps.<br>V.42: Error correction method.<br>V.42bis: Data compression method. |



# Index

---

---

## A

Address · XIX  
Analog · XIX  
ASCII · XIX  
Asynchronous · XIX  
AT commands · XIX  
Audio input · 23  
Audio input/output · II  
Audio output · 23  
Audio subsystem · 22  
Auto answer · XIX

---

## B

Bell standard · XIX  
bis · XIX  
Bit · XIX  
bps · XIX  
Bus · XIX  
Bus clock  
    ISA · 16  
Bus system · 22

---

## C

Carrier · XIX  
Carrier frequency · XIX  
CCITT · XX  
CD-ROM · XX  
Clock frequency · XX  
CNG tones · XX  
COM interface · 19; XX  
Command mode · XX  
CONFIG.SYS · XX  
CPU · XX  
Current consumption · 24

---

## D

Defragmenting the drive · 7  
Demodulation · XX  
Device Manager  
    Windows 95 · 19  
Digital · XX  
DMA channel · III; XX  
Driver · XX  
DSP · 1; XX  
DSR signal · XX

---

## F

Features · 1  
    sound and games · 2

---

## H

Hayes · XXI

---

## I

I/O addresses · V  
IDE · XXI  
Installing Mwave Multimedia  
    Adapter · 5  
Interface · XXI  
Interrupt · XXII  
IRQ · 15; IV  
ISA bus · XXII

---

## M

Microphone input · 22; II  
Microphone types · 22  
MIDI/joystick connector · II  
Mikrofon · 3  
Modem · XXII  
Modem data · 24  
Modem test · 11  
Mwave · XXII  
Mwave MDSP-2780 · 22  
Mwave Multimedia Adapter  
    diagram · 4  
Mwave Multimedia software  
    installing · 7  
    uninstalling · 13  
Mwave Quick Test · 11  
Mwave technology · 1

---

## P

PBX · 20  
Pin assignments · I  
Plug & Play · 2  
Problems  
    General · 16  
    installation · 15  
    Modem · 19  
    sound · 20  
Processor · 22

---

## R

Receive rate · 22  
RJ-11 Socket · 22

---

## *S*

Sampling rate · 22  
SET command · 15  
Sound test · 13  
Soundblaster Pro compatibility  
· 2  
System requirements · 3

---

## *T*

Technical data · 22

Telecommunications · XXIII  
Telefonkabel · 3  
Telephone connection · I  
Telephone subsystem · 22  
Transmit rate · 22

---

## *V*

V. standards · XXIII