



# Index

- accelerator
  - benefits 3
  - damage from electrostatic discharge 3
  - handling 3
  - installing 6
  - purpose of 1
  - selecting 14
- adjusting screen color 17
- bandwidths 3
- BBS 4
- Button display 12
- Card Selection button 15
- CompuServe 4
- computer
  - installed Number Nine accelerators in 15
  - PCI slots in 15
  - restarting 9
- configuration utilities. *See* utilities
- connectors 2
- contact information 20
- cursor color 18
- Cursor utility 18
- customer support. *See also* contact information
  - BBS 4
  - CompuServe 4
  - telephone support 4
  - World Wide Web 4
- driver 9
- electrostatic discharge 3
- ferrite cores 8
- gamma corrections 17
- Gamma utility 18
- HawkEye
  - control panel 11
  - defined 9
  - installing 9
- HawkEye control panel
  - layout 12
  - opening 11
- hotkeys 18
- Icon display 14
- installing
  - accelerator 6
  - driver 9
  - ferrite cores 8
  - utilities 9

---



- kit 3
- monitor cable
  - disconnecting 6
  - with BNC-type connectors 7
- monitor settings
  - adding 10
  - changing 10
  - resetting to default 10
- monitor switches 6
- N key 10
- offsets 17
- on-screen help 12
- parameters
  - current setting 16
  - displayed 15
- Quick Reference 23
- R key 10
- ReadMe 1st file 5
- removing power 6
- restarting the computer 9
- Saver utility 17
- screen color 17
- screen saver
  - activating from hot spot 17
  - activating with timer 17
  - interrupting 17
  - using 16
  - using logo for 17
- telephone support 4
- troubleshooting 21
- utilities
  - Cursor 18
  - Gamma 18
  - installing 9
  - parameters associated with 16
  - Quick Reference 23
  - Saver 17
  - selecting 15
  - Window 18
  - Zoom 18
- Warranty Registration Card 4
- Window display 15
- Window utility 18
- window-drag 18
- World Wide Web site 4
- Zoom utility 18

